

For lightweight touring,
durability, and control in
split mode...

the **SPARK** **PIN**
system

www.sparkrandd.com

Read the back for important instructions

SPARK **R&D**
The splitboard binding company.



Blaze/Burner



Fuse/Ignition



Bracket Only

Rider: Sean Busby Photo: Mollie Busby

WARNING!


Your new LT Pins are made of Aluminum and are only to be used with our LT Bracket. Do NOT use the LT Pins in Voile touring brackets. If you do, the pins will be destroyed and will not be covered under warranty.

How to install:

Remove your current touring bracket assembly by backing out the three screws holding it in place. Switch it out with your new LT Bracket and re-tighten screws. Done. Now, attach pin leash loops underneath the toe buckles (you will have to unscrew each buckle). Adjust the leash length so it's not too tight and not too sloppy, and then replace the buckle. Do one foot at a time so you can use the other one as reference.



Mr. Chomps Compatibility

Note: You do not need the flat plastic shim underneath the LT bracket like you did with the Voile touring brackets. 

What are these two pieces of black plastic included in this package? In order to use your Mr. Chomps Crampons with the LT touring brackets you will need to replace the long plastic centering blocks with these shorter plastic centering blocks. Just unscrew your current ones and screw in the new ones (do not over tighten). You're good to go!

Not a Chomps owner yet? Keep these bars in a safe place, as you'll need them down the road!

For questions contact sales@sparkrandd.com or call 406-580-7674