

TESLA T1 RISER KIT



SPARK R&D

The splitboard binding company.



sparkrandd.com

T1 Riser Kit - Setup Guide

Parts Included:

- 6x 20mm Screws
- 4x 18mm Screws
- 6x Lock Washers
- 2x Touring Bracket Riser
- 2x Tesla Heel Rest Riser

1 If already installed on your splitboard, remove the Touring Brackets and Heel Rests. Save the screws in your spare parts kit.

2 Sort your new screws, there are six 20mm screws and four 18mm screws.



3 Place the Touring Bracket Riser on the board and then the Touring Bracket on top of it. Place a lock washer on each hole in the Touring Bracket, and then insert and tighten a 20mm screw in each hole of the Touring Bracket.

4 Place the Heel Rest Riser on the board, and then the Heel Rest on top of it. Be sure that the arrow on the Heel Rest is pointing toward the nose of the board. Then insert and tighten an 18mm screw in each hole of the Heel Rest. Enjoy!

