



Product Guide and Setup for Mr. Chomps Crampons

Note: the 2010/2011 model of Mr. Chomps are compatible with either single or dual climbing wires!


MR. CHOMPS SPECIFICATIONS

	Sizing	Inside Width	Weight (pair)
Regular	boards 26cm waist or less (most boards)	13.8cm	14.8oz
Wide	boards over 26cm waist (select boards)	14.8cm	15.2oz

Before use:

(A) Gray flat shims are shipped with the crampons. Swap these with the Voile pin guides underneath the touring brackets. (you'll need a #3 Phillips head screw driver).

(B) When you're done it will look like this.



How they work:



Mr. Chomps grabs onto the underside of the pin.



To install your crampons rotate the bindings forward and hook the crampon underneath the pin.



When the skin track is steeper, flip up the heel rest (you have a choice of two heights if you have dual climbing wires seen below). For maximum Chomp, use the riser on the crampon as well. For ease of skinning, the crampon will float over the snow on your forward stride and dig in when you switch feet. If the track is really steep or really slick, lock down the crampon with the heel rest to keep it solid.



We hope you enjoy your new Mr. Chomps crampons.
Questions? Please feel free to call or email us: 406-580-7674, sales@sparkrandd.com

See you in the backcountry!



PHONE: 406.580.7674
WEB: www.sparkrandd.com
FAX: 866.323.7948
MAILING: PO Box 3284 Bozeman MT 59772

