



To install your crampons rotate the bindings forward and hook the crampon underneath the touring pin.

IMPORTANT: Make sure the crampon is fully engaged on the pin. Failure to do so can result in damaged or lost crampons.



When the skin track is steeper, flip up the heel rests on your board and Mr. Chomps. For maximum grip from your skis and crampons, stand up straight and keep weight on your heels.

Now, drop them in and enjoy 4-wheel drive for your splitboard!

