




Based out of Bozeman, Montana, USA, Spark R&D is rider owned and operated, dedicated to pushing innovation in splitboarding since 2005. Your feedback and enthusiasm for backcountry riding has continued to inspire our creativity. Thank you for supporting Spark R&D.

WARNING! THESE BINDINGS WILL CHANGE YOUR LIFE
ENSURE AN EPIC FIRST DAY OUT: READ CAREFULLY BEFORE YOU STRAP IN.

Stay safe in the backcountry.
Splitboard with a buddy.
Take a transceiver, shovel and probe and know how to use them.
Check your local avalanche center advisory.

See your local shop or our website for more detailed instructions.



CHECK YOUR BOARD SET-UP (FACTORY SPLITBOARDS)

Spark Pucks:

- Use the two Spark Pucks with the words “Toeside Edge” on the toeside edge of your board. Use the other two pucks on the heelside edge of your board.
- Insert an aluminum center disk in each puck with the angle markers pointing toward the board centerline.
- Insert the screws through the pucks and leave loose.
- Place the guide tool over the pucks. Slide around until stance is just right and then tighten screws. Note: For Arc and Magneto bindings you can also place the mini guide tool between the pucks, slide the bindings on, and snap down the snap ramps. Cutouts through the baseplates allow access to the screws, and stance adjustment with the bindings on the board.

Voilé Universal Pucks:

- Use the Voilé pucks with the inline discs (ONE slot) on the HEEL side of the board for best heel/toe centering. Note: if you are using a Burton, Voilé, or K2 splitboard with channels you will only have parallel slot channel pucks.
- For stance angles between roughly -12 and 12 degrees the A on the inline disc should point toward the board centerline. For steeper angles, the B should point toward the board centerline.
- Use the Voilé pucks with parallel discs (TWO slot) on the TOE side of the board.
- Rotating the parallel disc 180 degrees will shift your stance toward the nose or tail of the board. Use this to adjust your stance width.

All Pucks:

- The outside length from puck to puck should be 7 5/8” (19.35cm).
- The bindings should slide on easily. If it feels like they are jamming, check your puck alignment and make adjustments as necessary.
- If your pucks are brand new, the fit might feel tight but will break in after just a couple of times changing over. If still too tight sand lightly on the top and sides of the pucks with the included sandpaper. Check fit while pucks are wet.
- With the bindings on the pucks in ride mode, you should be able to easily snap down the toe ramp. If you can’t, loosen the screws and nudge the toeside puck in slightly.

Touring Brackets:

- Attach the touring brackets with the yellow patched screws.

Heel Rests:

- Orient the heel rests so that the arrow points toward the nose of the board. Attach heel rests with the blue patched screws.
- If you have a DIY Splitboard using ski screws: you will need to use 5.5 x 11.5 mm ski screws for the heel rests. Ski screws used with Voilé climbing heels are too long and will bubble your base. If you need these shorter screws and cannot find them locally, please contact us.

THESE BINDINGS ARE FULLY ADJUSTABLE!

If the fit is not perfect out of the box, use the included Spark pocket tool to adjust toe and ankle strap lengths, heel cup position, and highback rotation. Then throw the tool in your pack so it’s always with you when you’re out in the backcountry.

Check to see that all the screws in your bindings are tight from time to time for uninterrupted shredding.